

Quick Features Overview

Series 5000 Vending Machine




The chute rests just above a 5-gallon bucket sitting on the ground in its lowest position. In its highest position, the chute can fill containers in the back of a pickup truck.



The chute handle allows customers to stop and start the flow of corn to fill multiple containers, the same can be done from the touch screen.



118 Bushel and 150 Bushel capacities are available. The machine keeps track of how much corn it has and will notify you over email if it needs to be filled.



Simple and easy to use touch screen interface, allows customers to buy any amount of corn. Customers can even buy small amounts such as 50lbs and less. It accepts payments in the form of cash or card and gives email notifications when a sale has been made.



When customers buy corn, they are given a counter like a gas pump that shows how much is remaining. They can choose to start and stop the auger from the touch screen or the push button on the chute handle.



If for any reason the auger becomes jammed on foreign objects in the corn or customers allow the chute to become buried, the machine has a safety feature to alert the customer. The auger is stopped, and a friendly screen is displayed to let them know to make sure the chute is clear. This prevents customers from being shorted and prevents unnecessary wear on your machine.



The hidden administrator panel is only accessible by owners and allows you to adjust any feature of your machine. You can adjust the fill level, price and so much more with just the touch of a button.



Three step calibration allows you to quickly calibrate your machine to the weight differences of wet or dry corn. If you prefer to adjust these values manually you can do that too.



You can manage your email notifications from here, your machine can send you an email if a problem has been detected. If you have questions about any problem we are available to support our products 24/7 with our owner support service.

